

Home

Price Guide

Setup

Hyperlite

Old Page



1



2



3

Assembling Hyperlite is quick and easy.

First, install the bottom trusses between the lower half of the uprights. The bottom of the bottom connection should be flush to the bottom of the extrusion. Both should be on the floor with the truss 1/2" off the floor.

Setup